



Shaker, Bird & Teddy Set

Cause and effect with a different action each time: turn, press, knock. Supports prediction, fine motor control and sensory exploration of sounds and facial expressions.

CONTENTS

3 toys

MARKET

Dual — Home & Education

WHAT IS IN THE SET



Magic Shaker

13.5 × 5.5 × 12 cm



Crazy Eyed Bird

9.5 × 9.5 × 15 cm



Roly Poly Teddy Bear

9.5 × 8.5 × 12 cm

WHAT CHILDREN LEARN



Cause & effect

Turn, push, knock — three different actions, three reliable results. Prediction begins here.



Fine motor

Two-handed turning of the shaker, finger-tip work on the bird's eyes, a whole-hand push on the teddy.



Visual tracking

Beads flowing chamber to chamber, a bear rocking back to centre — slow movement the eye can follow.



Language

Up and down, in and out, again and stop. The bird's faces invite happy, sad, surprised.



Emotional literacy

The bird's movable eyes make faces a child can copy, name and laugh at.



Social skills

Push the teddy to a friend and it comes back. A wobble is a turn a baby can take.

ONE SET, FIVE YEARS OF PLAY



TRY THIS ON DAY ONE



Watch It Pour

6-12 months · Turn the shaker slowly so the beads flow; let the child's eyes follow them down.



Wobble Back

6-15 months · Push the teddy over, let it rock back. Wait for the child to push it too.



Make a Face

12 months - 3 years · Move the bird's eyes into a new position and copy the face together.

TOPIC LINKS

Cause and effect

Faces and feelings

Up and down

In and out

Sounds

Taking turns

