

CLASSIC · ACTIVITY TOYS

Push and Go Teddy

Item number 76028

A teddy on a free-wheeling bike that sets off when his head is pressed down. Toddlers from twelve months press, watch him go, then follow to retrieve him and repeat. His head clicks as it turns and the toy makes a pleasant rattling sound as it rolls. The chase gives new walkers a reason to move, while the character invites talk and pretend play.



KEY FEATURES

- Press and go**
Press teddy's head down and the bike rolls away.
- Clicking head**
Teddy's head turns with a click.
- Free wheeling**
Rolls freely across the floor.
- Rattling sound**
A gentle rattle sounds as teddy travels.

LEARNING & DEVELOPMENT

- Movement & gross motor**
Following teddy across the floor builds confidence in walking and balancing.
- Cause and effect**
Pressing the head makes the bike go, a clear action with an immediate result.
- Imaginative play**
Teddy riding his bike becomes a character to talk to and play with.
- Fine motor skills**
Pressing the head and turning it to click practises hand control.

PRODUCT INFORMATION

Specifications from the TOLO product database

Age	12 months +
Item number	76028
UPC / EAN	019287760286
Contents	Push and Go Teddy

Packaging dimensions	13.5 × 9 × 16.5 cm
Product weight	0.25 kg
Master carton	24 pcs · 42.5 × 38 × 35.5 cm · 0.057 m ³ · 8.1 kg gross

Related TOLO Classic activity toys include Roly Poly Teddy Bear 76025 and the Clip On Friends Teddy Bear 76120.

